

5.1.6 Wireless Communications

Where a generating system's protection relay (anti-islanding relay) and import/export monitoring device is remote from the EG system's isolating device, a wireless communication system contained within the customer's site may be used. The generating system's protection relay and import/export monitoring device utilising wireless communication link shall be the customer's responsibility and:

1. Have a fail-safe system disconnecting the generating system from the distribution network upon failure of any generating system protection relay's hardware/software; and
2. Disconnect the generating system from the distribution network for any loss of communications that would inhibit the correct operation of the protection system longer than 5 seconds.

WARNING: Printed copies of this document ARE DEEMED UNCONTROLLED. The most up-to-date version is located on the Intranet\Internet.