

How to - switch off your solar PV system

If your solar system has a 'shutdown procedure' detailed on the equipment or in the user guide, follow it.

If your solar system doesn't, the general process to turn off your solar system is:

- go to your switchboard and open it. Locate the solar supply main switch and flick the switch to the off position.
- go to your inverter and find the switch marked PV Array and DC Isolator. Turn this switch to the off position (in some cases there will be two switches).
- your inverter may have a switch marked Inverter Isolator. If it does, turn this switch to the off position. If you cannot locate this switch on your inverter, skip this step.

Your solar PV system should now be switched off.

To re-start your system, follow this guide in reverse order.

**Thank you
for helping us keep the lights on.**


For New Energy Services please contact
newenergyservices@sapowernetworks.com.au
or call 13 12 61 opt. 2.
sapowernetworks.co/Solar
or scan the QR code:



Example solar supply main switch



Example PV Array and DC isolator



Example shutdown procedure